

Acme Sanitary Ware Co. Ltd.

1/F, Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 Email: acme@acmesanitary.com.hk
Website: www.acmesanitary.com.hk



PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

SANITARY WARE SPECIFICATION SHEET

Item Descriptions	Idecor (PRC) 304 Stainless steel single bowl insert sink with waste fittings and overflow hole	Illustration/ Drawing	
Dimensions	L428 x W428 x H180 mm (Overall) L372 x W372 x H180 mm (Bowl)	II-II	
Model	E1813		
Material	Stainless Steel 304		
Manufacturer	Idecor (PRC)		
Source	Acme Sanitary Ware Co. Ltd Mr. Eric Wong/ Mr. Don Yuen		
Contact Tel/Fax	(852) 2388-7171 / (852) 2710-8012		
E-mail	acme@acmesanitary.com.hk		
Website	www.acmesanitary.com.hk	Ø428 Ø372	

Note:		

^{*} All information of the above is for reference only. No prior notice is made if any changes.



Acme Sanitary Ware Co. Ltd.

1/F, Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 Email: acme@acmesanitary.com.hk Since 1949 Website: www.acmesanitary.com.hk




INSTALLATION


INSTALL THE SINK




NOTE: You may require different, more specialized tools to install this sink to countertop materials other than wood or wood composites.




1. Clean the countertop, Track the cutout template outline onto the countertop. Make sure the sink will not interfere with the cabinet.




2. Drill a pilot hole inside the cutting line. Using a jig or keyhole saw, cut along the outline to cut out the opening in the countertop.




3. By trimming machine, files and sandpaper polish the cut edge, for a desired fillet.



4. Paste sealing tape along the back rim of the sink. Apply a bead of quality sealant to maximize sealing effect.



5. Position the sink onto the cut-out area.



6. Attach mounting clips.

Note: 1. Wipe away any excess sealant from the countertop with a dry cloth;

- 2. Verify that there are no gaps;
- 3. Allow the sealant to cure for at least 30 minutes before proceeding.