







## Acme Sanitary Ware Co Ltd

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong

Tel: 2388 7171 Fax: 2710 8012

E-mail: acme@acmesanitary.com.hk

Website: www.acmesanitaryware.com.hk

PROJECT		REF		REV	ITEM CODE	
LOCATION		DATE			PAGE	

# SANITARY WARE SPECIFICATION SHEET

## PLUG-IN SYSTEM

The Machflow® Plug-in technology is an easy, practical, fast and secure system to install and uninstall a hand dryer, making maintenance much more efficient and reducing at the same time its costs.

With the Machflow® Plug-in technology a hand dryer can be installed in a few steps and it can be replaced in less than 10 seconds thanks to its SMED (Single-Minute Exchange of Die) system. Furthermore its maintenance can be carried out better at the maintenance workshop and it is totally secure against electric shocks. All of these benefits allow you to reduce the

This fast install/uninstall technology to the wall is **optional** and it is carried out by means of a special kit code: KTP009.

Installation of the dryer with this system is as follows



1 The Plug in Kit is compatible with the Machflow hand dryer and the Machflow hairdryer

2 Unscrew the cover screws (x2)

3 Remove the cover by a rotating movement  
**ATTENTION:** To prevent electrical shock, disconnect the power source before installing the Plug in Kit

4 Disconnect the wires and remove the power strip

5 Unscrew the wall mount screws (x4)

6 Remove the silent blocks from the back of the unit (x4)

7 Route the wires through the holes to the back of the unit as shown on the picture

8 At the back of the unit, connect the wires to the fast connector following the engraved letters (N, L and Earth)

9 Fix the fast connector to the back of the unit using 2 screws

10 Close the dryer cover

11 Screw the cover fixing screws (x2)  
Your dryer is now ready to be used on a Plug-in base

12 Same wall holes may be used for the Plug-in installation

13 Route the wires through the Plug-in base as shown on the picture

14 Screw the Plug-in base to the wall (x4)

15 Connect the wires to the fast connector following the engraved

16 Fix the fast connector to the Plug-in base using 2 screws

17 Close the security cover  
Your Plug-in base is now ready to be used with a Plug-in dryer

18 Mount the dryer over the Plug-in base with a from top to down movement

19 Screw the safety screw  
Your dryer is ready to be used

Note: <https://youtu.be/qDUU0ues3DE>



\* All information of the above is for the reference only. No prior notice is made if any changes.

Source: Mediclinics,





# Acme Sanitary Ware Co Ltd

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong









Tel: 2388 7171 Fax: 2710 8012

E-mail: acme@acmesanitary.com.hk

Website: www.acmesanitaryware.com.hk

## HAND DRYERS

Table

	MODEL	OPERATION		DIMENSIONS (mm)	Ionizer	HEPA filter media	Drain Pipe	ADJUSTABLE POWER	MOTOR			TRAFFIC FREQUENCY		
		manual	sensor						induction	brush	brushless	HIGH	MEDIUM	LOW
	dualflowplus													
	M24A		●	L320xD228xH665	●	●	●				●	●		
	M24AB		●		●	●	●				●	●		
	M24ACS		●		●	●	●				●	●		
	M14A		●		●	●	●	●		●		●		
	M14AB		●		●	●	●	●		●		●		
	M14ACS		●		●	●	●	●		●		●		
	machflowplus / machflow													
	M19A		●	L213xD170xH330	●	●		●			●	●		
	M19AB		●		●	●		●			●	●		
	M19AC		●		●	●		●			●	●		
	M19ACS		●		●	●		●			●	●		
	M09A		●		●	●		●		●		●		
	M09AB		●		●	●		●		●		●		
	M09AC		●		●	●		●		●		●		
	M09ACS		●		●	●		●		●		●		
	speedflowplus / speedflow													
	M17A		●	L290xD100xH270 (INSIDE CABINET)	●	●		●		●		●		
	M17AB		●		●	●		●		●		●		
	M17AC		●		●	●		●		●		●		
	M17ACS		●		●	●		●		●		●		
	M17AF		●		●	●		●		●		●		
	M06A		●					●		●		●		
	M06AB		●					●		●		●		
	M06AC		●					●		●		●		
	M06ACS		●					●		●		●		
	M06AF		●					●		●		●		
	saniflow													
	E05	●		L276xD214xH245						●		●		
	E05B	●								●		●		
	E05C	●								●		●		
	E05CS	●		L282xD215xH255						●		●		
	E85	●								●		●		
	E88	●								●		●		
	E88B	●		L278xD212xH248						●		●		
	E88C	●								●		●		
	E88CS	●								●		●		
	E88O	●								●		●		
	E05A		●		L276xD214xH245	●					●		●	
	E05AB		●	●						●		●		
	E05AC		●	●						●		●		
	E05ACS		●	L282xD215xH255	●					●		●		
E85A		●	●						●		●			
E88A		●	●						●		●			
E88AB		●	L278xD212xH248	●					●		●			
E88AC		●		●					●		●			
E88ACS		●		●					●		●			
E88AO		●		●					●		●			
	mediflow													
	M02A		●	L275xD164xH325	●					●			●	
	M02AB		●		●					●			●	
	M02AC		●		●					●			●	
	M02ACS		●		●					●			●	
	M03A		●		●					●			●	
	M03AB		●		●					●			●	
	M03AC		●		●					●			●	
	M03ACS		●		●					●			●	
	optima													
	M99A		●	L260xD150xH302	●				●				●	
	M99AC		●		●				●				●	
	M99ACS		●		●				●				●	
	juniorplus													
	M88APLUS		●	L253xD150xH303	●				●				●	
	M88PLUS	●		L253xD153xH303					●				●	
	smartflow													
	M04A		●	L147xD138xH259	●					●				●
	M04AC		●		●					●				●
	M04ACS		●		●					●				●

● Optional