# Acme Sanitary Ware Co Ltd Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong

Acme Building, 22-28 Nanking Street, Kow Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

#### SANITARY WARE SPECIFICATION SHEET

Item Descriptions Stern (Israel) "Quadrat SD 2030" Chrome plated wall mounted liquid soap dispenser in AC Supply with 5m wire AC 110-240 Vac 50/60Hz to 12V 2.5A IP68 waterproof switching transformer **Dimensions** L124 x W28 x H28 mm Model Quadrat Soap Dispenser 2030 E Code Number 351930 Chrome Plated Finish Supplier Acme Sanitary Ware Co. Ltd Mr. Eric Wong/ Mr. Don Yuen Contact Tel/Fax (852) 2388-7171 / (852) 2710-8012 E-mail acme@acmesanitary.com.hk Website www.acmesanitary.com.hk **OUADRAT SOAP DISPENSER 2030 E** 

#### QUADRAT SOAP DISPENSER 2030 E Ref # 351930

Touch free electronic soap dispenser for installations in brick walls. Activated by infrared sensor. Chrome plated body, other finishes available. Includes a 1 liter soap bottle and bottle support. Optional for remote installation: extension cable and longer piping. The following functions can be performed by using Stern remote control: soap quantity selection, refill the soap tank, temporary off, coming back to factory settings.


#### **Application:**

Closing automatically without dripping, Stern's touch free soap dispenser helps to ensure that the bathroom will stay organized and neat. Combined with Quadrat touch free electronic faucet, it creates a germ-free and automated environment.

#### Use:

Touch free electronic soap dispenser. The soap dispenser is activated automatically when the users bring their hands within the sensor range and stops when the users remove their hands.

PRODUCT SPECIFICATION					
Power supply	6D Alkaline battery*, plug-in transformer, output : 12 VDC 0.5A, or hardwired (1A/2.5A)				
Soap:	non-proprietary, viscosity up to 3800 cP for liquid soap				
Tank capacity:	33.8 oz (1L) bottle or 203 oz (6L) Tank/Bracket				
Soap adjustability:	from 0.02 oz (0.7 ml) to 0.08 oz (2.3 ml)				
Accessory	07100008 remote control for soap dispenser				
Detection range:	+/- 4"				
Dispenser hole diameter	7/8" to 1" (23 to 24 mm)				
Spare parts recommended:					
07220279	10-pack sensor kit				
07222013	soap dispenser pump (liquid soap version)				
06522080	12 V transformer				



<sup>\*</sup> All information of the above is for the reference only. No prior notice is made if any changes.






Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

### **SPARE PARTS LIST**



Note: In order to locate the relevant spare part, please check the corresponding parts and part mumber in the drawing. Minimum order quantity will be required.

<sup>\*</sup> All information of the above is for the reference only. No prior notice is made if any changes.



Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



## **INSTALLATION**

Tubular Soap Dispenser 2030 B / E Quadrat Soap Dispenser 2030 B / E

#### Step 1 - Preparing for installation


- 1. Disconnect the soap dispenser body with the rosette by unscrewing the set screw.
- 2. Cut an adequate opening in the wall for the dimensions of the soap dispenser base (where you want to install the spout), and the corrugated tube.




### Step 2 - Installing the soap dispenser

1. Mount the soap dispenser base to the opening cut in the wall, and set it using the two small anchors provided.

Important: The soap dispenser base should be installed so that the outside surface of the finished wall falls between the minimum and maximum lines marked at the base.



2. Assemble the temporary protective soap dispenser base cover.






Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk




# INSTALLATION

Tubular Soap Dispenser 2030 B / E Quadrat Soap Dispenser 2030 B / E

3. Assemble the corrugated tube to the soap dispenser base and make sure it will stay outside of the wall when tiling.



- 4. Once the works on electricity, plumbing and tiles have been finished, insert the wall rosette through the soap dispenser base.
- 5. Cut the temporary soap dispenser base cover.
- 6. Fix the soap dispenser spout by inserting the nipple into the soap dispenser base and tighten the screw.
- 7. Pull the four way connector and the power supply connector out of the soap dispenser base, and lead it through the corrugated tube.





Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



## **INSTALLATION**

Tubular Soap Dispenser 2030 B / E Quadrat Soap Dispenser 2030 B / E

#### Step 3 - Connecting the power source

1. Remove the protective sticker covering the sensor. Keep away from the sensor range and check that no objects are in front of the sensor.



2. a. Connect the motor connector to the power source connector. Please note that since the connector is water proof, some friction might apply.


**Important:** the 4 contacts connector should be connected properly so that the white o-ring is not visible and a clicking sound is heard.

**Pay attention:** If the 4 contacts connectors will not be connected properly, the motor will work continuously.





- b. For battery versions: install the battery box at the wall underneath the sink and connect the battery connector
- c. For transformer versions: plug the transformer into the electricity socket and connect the transformer connector



3. Wait about 10 seconds before you put your hands within the sensor range.





Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



## TROUBLE SHOOTING

