Acme Sanitary Ware Co Ltd



Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



Website	. www. acmesaniaryware.com					
PROJECT]	REF		REV	ITEM CODE	
LOCATION	D	ATE			PAGE	
S	ANITARY WA	ARE SPEC	IFICA	TION	SHEET	
Item DescriptionsStern (Israel) "Neptune Medical" Chrome plated exposed wall-mounted thermostatic sensor shower mixer in DC Supply with internal 9V battery box; top access 		ostatic with	Illustration/ Drawing			
Dimensions	sions L270 x W80 x H66 mm					
Model	Neptune Medical	1000 T				
Code Number	610250					
Finish	Chrome Plated					
Supplier	Acme Sanitary Wa Mr. Eric Wong/ M			G-3/4"	150	G-3/4"
Contact Tel/Fax	(852) 2388-7171 /	(852) 2710-8012				
E-mail	acme@acmesanitary.com.hk			ĮQ.	q	[DQ]
Website	www.acmesanitary.com.hk			r C		
NEPTUNE MEDICAL 1000 T Ref # 610250 Touch free electronic shower control operated by an infrared sensor.Includes a thermostatic mixer, non return valves, filters and thermostop at 38°. All components are located inside the product body. Low battery indicator included. The following settings can be changed by using the Stern remote control: sensor range, security time, delay in, delay out and on-off.						
Application: Combines an elegant design with high quality into a vandal resistant product. Helps washrooms to stay hygienic, safe and water saving. Prevents cross contamination and is ideal for hospitals and clinics. Use:						
	shower control.The shower r ange.	will be activated onc	e the user		tallation: mounted expo	sed

		PR	ODUCT AT A GI	LANCE		
Installation	Ex	Exposed wall-mounted				
Power Supply	Int	Internal 9V battery				
Operating pressure	0.5	0.5-8.0 bar / 7.0-116.0 PSI				
Water supply	Но	Hot and cold water				
Water Temperature	Maximum 38°C					
		ORD	ERING INFORM	AATION		
MODEL		CODE	POWER	ADDITIONAL FEATURES		
NEPTUNE MEDICAL 1000T NEPTUNE MEDICAL 1000T WITH BOTTOM OUTLET		610250	9V battery	Exposed installation		
		610255		Mixer for water temperature adjustment		
			OPTIONS			
OPTION				CODE		
Remote control					07100005	



* All information of the above is for the reference only. No prior notice is made if any changes.

Acme Sanitary Ware Co Ltd



Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



SPARE PARTS LIST Neptune Medical 1000T (610250) (\mathbb{O}) 0 -19 H 11 :---П 18 18 20 (17)(18 16 11 12 13 14 15 1 10 2 Quantity Part Number Description Cat. No. Seals and Screws Kit 07210075 O-ring O-ring 12 7 9 2 2 Screw 8 Screw Sensor Kit 07220030 1 20 Infra Red Sensor 1 7 O-ring Thermostatic Cartridge Kit 07240021 _ 16 Thermostatic cartridge 1 17 Adapter 3 18 O-Ring Thermostatic Handle Kit 07110018 1 19 Stern Interoperable L S9V1.2WWPC1 07500065 Adapter for Handle 07055067 4 Cover for Battery 3 06500001 5 Nut for Thermostat 07055070 Cover Kit 07270070 Cover 10 1 2 9 O-ring Inlet Nipple Kit 07246033 Flat filter 12 2222 13 Nipple Valve Check Nut ¾" 14 15


Note: In order to locate the relevant spare part, please check the corresponding parts and part mumber in the drawing. Minimum order quantity will be required.

* All information of the above is for the reference only. No prior notice is made if any changes.





SHOWER INSTALLATION








SHOWER INSTALLATION

(5)

6

Proceed to mounting the shower on the eccentric unions.



Tighten the nuts carefully with a 30mm wrench.



STEP 2 – CONNECTING THE WATER SUPPLY AND OPERATING THE SHOWER

Turn on the central water supply and the shut-off valves and check for leaks. Remove the protective sticker that covers the sensor and wait 10 seconds before activating the shower.

IF THE RANGE IS UNSATISFACTORY, REFER TO THE SECTION TITLED "SETTING ADJUSTMENT".







ADJUSTING THE WATER TEMPERATURE








BATTERY REPLACEMENT

LOW BATTERY INDICATOR

The Neptune Medical 1000 T has an advanced battery level management system consisting of 2 steps. In the first step, the battery still has enough power to open and close the solenoid valve and allows the solenoid valve to open.

In the second step the battery might not have enough power to open and close the solenoid valve. In this case, the battery level management system does not allow the solenoid valve to open. Instead of providing an opening and closing pulse, the systems provides two closing pulses.

BATTERY REPLACEMENT INSTRUCTIONS







BATTERY REPLACEMENT

(4)	Replace the used battery with a new 9V battery. A Lithium battery is recommended.	NEW BATTERY
(5)	Put the battery protection cover back on.	COVER NEW BATTERY
(6)	Reconnect the connectors between the battery and the cap.	
(7)	Place the cap back into place and tighten the Allen screw.	

- Do not allow moisture or water into the system while the battery is being replaced.

- The interior of the shower control must be fully dry before reassembling the parts. If it is not fully dry, carefully dry it.

IMPORTANT: Spent batteries should not be disposed of with normal household waste. Contact your local authority for information on waste disposal and recycling.







SERVICE CHECK LIST

PROBLEM	INDICATOR	CAUSE	SOLUTION
No water coming out of the shower head:	1.Sensor flashes con- tinuously when user's hands are within the sensor's range.	Low battery.	Replace battery.
	2. Red light in the sen- sor does not flash once when user's hands are within the sensor's range.	1. Range is too short.	Increase the range.
		2. Range is too long.	Decrease the range.
		4. Unit is in "Security Mode"*	
		5. Sensor is picking up reflections from the washbasin or another object.	Eliminate cause of reflection.
	 Red light in the sen- sor flashes once when user's hands are within the sensor's range. 	1. Connectors between the electronic unit and solenoid are discon- nected.	Connect the electronic unit connectors to the solenoid.
		2. Check the solenoid valve.	Check the solenoid valve.
		4. The water supply pressure is higher than 8 bar.	Reduce the supply wate pressure.
Water flow does not stop:	1. Sensor flashes once when user's hands are within the sensor's range.	Check the solenoid valve.	Check the solenoid valve.
	2. Red light in the sensor does not flash once when user's hands	1. Sensor is dirty or covered	Clean or eliminate case of interference.
	are within the sensor's range.	2. Sensor is picking up reflections from mirror or another object.	Decrease the range or eliminate cause of reflection.

* "Security Mode": If the sensor is covered for more than 10 min. the shower will automatically shut off water flow.

To return to normal operation remove any blockage.